

(AgOps) – Kentorganite Loading

Significant Aspect: Kentorganite Storage, Kentorganite Transportation

Frequency: Capacity, Weather
(Frequency may decrease with variable rain levels)

Record / Documentation:
Scale Ticket
Log Sheet

Location: Solids Handling Building

Failure to follow procedure: Could result in a spill of Kentorganite.

Loading

- Back Tractor Trailer into Dewatering Building
- Load *Kentorganite* w/ Loader
Full @ visual
Average capacity 20 tons/load
Average coverage 2 tons/acre
- Cover load w/power assisted tarp
Move handle (counter-clockwise) to cover
(Make sure tarp/cover is horizontal before driving-off)
- Weigh Load @ Truck Scale
Log Load
Place ticket into reader
Engage reader
- Haul load to scheduled location