

SETTING FLOW ON EFFLUENT SAMPLER

1. 2 times every shift
2. check effluent flow meter and record flow
3. at effluent sampler press main menu
4. next screen press “Options”
5. next screen press “Level Adjust”
6. next screen enter inches so flow matches effluent meter